

Acumen Aluminum Hydraulic Jack

PSI to Tonnage Conversion Chart

PSI to Tonnage Conversion Chart				
PSI/Ton	120	150	165	200
1000	12	15	16.5	20
1500	18	22.5	24.75	30
2000	24	30	33	40
2500	30	37.5	41.25	50
3000	36	45	49.5	60
3500	42	52.5	57.75	70
4000	48	60	66	80
4500	54	67.5	74.25	90
5000	60	75	82.5	100
5500	66	82.5	90.75	110
6000	72	90	99	120
6500	78	97.5	107.25	130
7000	84	105	115.5	140
7500	90	112.5	123.75	150
8000	96	120	132	160
8500	102	127.5	140.25	170
9000	108	135	148.5	180
9500	114	142.5	156.75	190
10000	120 Tons	150 Tons	165 Tons	200 Tons